

MR-202-BK Cartridge to Remote Oil Filter Adapter

Installation instructions:

Note: Read all instructions thoroughly prior to starting installation.

Step 1: Remove existing Cartridge filter



Step 3: If not installing Scrader valve, lubricate 1/8" plug with oil and install with 3/16 hex wrench. See Note #1



Step 2: Test fit for alignment and clearance prior to O-ring installation.



Step 4: Install adapter with 1 1/8" socket. Helpful Hint: 90-degree fitting can be Apply oil to 90 degree fitting and/or Schrader valve and install. See Note #2



Step 3: Lubricate with oil, install body and tip O-ring.



installed using a 15/16" 12 point closed end wrench.



U.S. Patent 10,195,553 1

Step 5: Lubricate O-rings on -10AN fittings and install using 1" deep socket. Install Schrader valve using 7/16" deep socket. See Note #1

Step 6: Connect customer supplied hose and fittings.





Servicing instructions at Oil Change: Prior to draining engine oil from oil pan, and oil filter removal, apply 30 PSI minimum/60 PSI max to the Schrader valve, this will evacuate the oil retained in remote oil filter and external oil cooler if installed. Then, remove oil filter and replace.



Note #1 Teflon sealing tape may be used instead of oil on plug, 90 degree fitting or Schrader valve. Be certain to apply tape to threads only and not over the end, this will avoid possible contamination of oil system.

Note #2 Adapter body may be backed out up to 340 degrees from fully seated position to obtain desired mounting position/alignment, adapter will remain sealed.

U.S. Patent 10,195,553