

FS-500-BL


Installation Instructions

Note: Read all instructions thoroughly prior to starting installation.

- Remove cartridge filter cap and filter using 1 1/16" hex socket.
 Clean exposed surfaces of cartridge receiver.
- 4. Install body O-ring and lubricate with engine oil.



 Test fit - install adapter until fully seated. Determine which port will be utilized for the Schrader valve. Remove adapter.



5. Install 90-degree fitting with sealant tape (if using) and Schrader valve.



3. Apply sealant tape (not included) to hex plugs and install in unused ports using 3/16" hex wrench.

Caution: Apply to threads only, not over end of plug.



6. Install adapter using 1" deep socket, torque to 40 ft.lbs.



7. Install spin-on oil filter that contains 22x1.5mm threads (recommend FL-500 S or equivelant) run engine to temperature and check for leaks.



Servicing Instructions

- 1. Remove oil filler cap on engine.
- 2. Remove Schrader valve cap on adapter.
- 3. Using air chuck, apply 100 psi dry compressed air to Schrader valve for 4-5 seconds.
- 4. Wait 30 seconds and apply 100 psi dry compressed air for another 3 seconds.
- 5. Remove oil filter.