

## EVAC-S1 / EVAC-S2 / EVAC-S3 Installation Instructions



**Note: Read all instructions thoroughly prior to starting installation.**

1. Remove oil filter.



2. Using a clean cloth, remove oil and dirt from oil filter contact surface.



3. If using 90 degree fitting apply sealing tape. (not included)



4. Install 90-degree fitting and Schrader valve.



5. Ensure that the EVAC-U-FILTER Viton gasket is fully seated and dry. **Do not lubricate gasket.**



6. Install adapter and retaining nut. Using 1" deep socket, tighten to 5 ft.lbs. (snug)

**Do not over torque, the oil filter will provide sealing pressure. Use socket only, do not use adjustable or open end wrench.**



7. Lubricate oil filter gasket and install oil filter.

8. Start engine and check for leaks. Run engine to operating temperature and check for leaks again.



## **Servicing Instructions**

Prior to draining oil pan.

1. Remove oil filler cap on engine.
2. Remove Schrader valve cap on adapter.
3. Using air chuck, apply 100 psi dry compressed air to Schrader valve for 4-5 seconds.
4. Wait 30 seconds and apply 100 psi dry compressed air for another 3 seconds.
5. Remove oil filter.