



## Inverted Remote Mount Installation Instructions

Prior to installation determine -

- Mounting location (mid-engine level or above)
- Mounting bracket orientation (can be mounted either side of Remote Mount body in 90° rotational increments)
- Hose connection location and routing

Once mounting and hose path is established –

- Use mounting bracket as template to mark and drill holes
- Attach mounting bracket to Remote Mount Body using supplied cap screws and lock washers
- Install -10AN fittings and plugs with O-rings (lubricate O-rings)
- Helpful Hint: Using a sharp punch, create small hole at top of filter prior to removal at next oil change. This will allow oil to drain from filter before removing.

We recommend minimum 5/8" ID hose rated for oil and fuel.